









## Change List

V2

- 1. Change EEPROM U501 from 24CW640T-I/CS0668 to M24512-DFCS6TP/K
- 2. Remove zero ohm resistors: R407, R408, R502, R503, R505, R506 (I2C zero ohm on SDA/SCL)
- 3. Add MOSFET PMCA14UNYL in series with R307
- 4. Add 5 ohm resistor (R301) in parallel with R307 / MOSFET PMCA14UNYL (Q301)
- 5. Remove R309 (ADDR pull down)
- 6. Load C418 and add C419 to account for cap & IC corners
- 7. Change R511 from 200k to 1M
- 8. R303 jumper in parallel with MOSFET Q301 (To bypass the part)
- 9. Added C102 15pF desense cap to J101 VSYS voltage rail
- 10. Add C103 22uF capacitor close to superflex connector
- 11. Add C419 22uF capacitor to the PP\_VLED output (DNI)
- 12. Add TPs to match GTK test point setup

V3.

- 1. Remove C103 (22uF) capacitor near superflex connector
- 2. Add 2.2k I2C pullup resistors powered by PMIC 1.8V rail
- 3. Rename LD\_I2C\_Sxx as PANEL\_I2C\_Sxx and disconnect pin 9 and 11 on the superflex connector
- 4. Remove R205 (PMIC IRQ L) zero ohm resistor
- 5. Remove R512 (LCOS\_GPIO0) zero ohm resistor
- 6. R306 (LD\_ENABLE\_H) now PD instead of PU and populated
- 7. R203 changed from 0201 to 01005 for testing
- 8. R401 1M PD on PANEL\_RESET\_H near J401
- 9. Updated L201 to DFE252007F-1R5M=P2

	845-03108-01-1p3										ı
	<b>∞</b> Meta	CONFIDENTIALITY NOT BE THIS DOCUMENT IS CONFIDENTIAL AND CONTAINS DISIGNS AND OTHER PROPRIETARY IN RORMATION OF META PLATFORMS TECHNOLOGIES. LICAN DITS AFFILIATES. THIS DOCUMENT		TITLE  846-02196-01, SCH, DISPLAY DRIVER BOARD, PICTOR					Monday, March 06,		23
		AN OTHE INFORMATION IT DISCLOSED OR USED, IN W INCLUDING MANUFACTUR	CONTAINS MAY NOT BE DISPICATED	SHEET DESCRIPTION  06-Change_List		SIZE C	TYPE SCH	PART NUMBER 846-02196-01	REVISION 1.0.3	SHEET 6 of 6	